



Installation
Instruction for
KONI-Coil-over-Kit

Front






- Lift vehicle and remove wheels.
- **Note:** If the vehicle is equipped with an automatic headlight level sensors the connection must be removed from the control arm to the sensor, in order to avoid damage.
- Remove the screw from the ABS cable bracket (1).
- Remove the upper sway bar link attaching nut (2).
- Loosen lower pinch bolt (3) and remove.
- Slide spindle off of strut. (**note: if necessary the original spring may need to be compressed with a suitable spring compressor (5) or the drive shaft may have to be disconnected at the transmission.**)
- Remove three bolts from the upper strut mount (6) and strut can be removed out and downward.
- Remove original spring seat and upper strut mount.
- Install bearing assembly on KONI strut, reference parts list page 3.
- Installation is the reverse of removal.
- Lower spring seat height (X distance between center of the lower fixing bolt and the spring seat upper edge, Value of X must be)
Permissible axle load:
to max. 1130 kg X must be 240 to 260 mm
to max. 1015 kg X must be 230 to 260 mm


Application: Audi A3, VW Golf V, Golf V Plus, Jetta, Seat Altea, Toledo, Leon	Part Number.: 1150 5080	
Date: 04.06.2008	Page: 1 of 3	KONI North America ITT

Installation
Instruction for
KONI-Coil-over-Kit

Rear



5.



Z

	M10	M12	M14	M16	M18
	35 Nm (26 N.m)	50 Nm (37 N.m)	80 Nm (59 N.m)	120 Nm (89 N.m)	165 Nm (122 N.m)
	45 Nm (33 N.m)	80 Nm (59 N.m)	125 Nm (92 N.m)	180 Nm (133 N.m)	250 Nm (185 N.m)
	—	50 Nm (37 N.m)	80 Nm (59 N.m)	120 Nm (89 N.m)	165 Nm (122 N.m)

- Lift vehicle and remove wheels.
- **Note:** If the vehicle is equipped with an automatic headlight level sensors the connection must be removed from the control arm to the sensor, in order to avoid damage.
- Raise the rear control arm with jacking equipment (1) or appropriate tool, remove bolt (2). **note:** the swaybar affects the control arm. By lowering the wishbone original - spring ease and these take
- Bolts (3, 4 u. 5) Loosen and remove.
- Remove shock absorber (6) with upper attachment.
- Assemble unit fig. 3 using parts list on page 3.
- Installation is the reverse of removal.
- Note: When installing the KONI height jacker and spring, utilize parts list on page 3 and fig. 4 do not forget 2 black plastic disks
- Height Jacker settings (distance between upper edge spring and original spring platform Photo 4, measure of X).
permissible axle load:
to max. 1080 kg → 30 to 40 mm
to max. 1040 kg → 25 to 40 mm
to max. 990 kg → 20 to 40mm
- Fixing bolt (1 u. 2) tighten when suspension is loaded.

Application: **Audi A3, VW Golf V, Golf V Plus, Jetta, Seat Altea, Toledo, Leon**

Part Number.: **1150 5080**

Page: 2 of 3

Date: 04.06.2008

KONI North America
ITT



1. Plastic Washer
2. Bump Rubber
3. Dust cover
4. Spring bearing
5. Upper mount
6. Nut M 14 * 1,5 with Lockwasher
7. Replacement strut with threaded perches
8. Front Spring

9. Plastic Washer
10. Bump rubber with dustcover
11. Upper mount
12. Nut M 10 * 1
13. Rear-Damperr
14. Rear-Spring
15. Black plastic disk
16. Height Jacker.

Parts 4, 5, 10 and 11 are original VW parts.

Application: Audi A3, VW Golf V, Golf V Plus, Jetta, Seat Altea, Toledo, Leon	Part Number.: 1150 5080	
Date: 04.06.2008		Page: 3 of 3
		KONI North America ITT